



Brick Veneer Detail

scale 1:2

Applicable for:
DS1900

Notes:

- DO NOT SCALE OFF THESE DRAWINGS
- All dimensions are in mm.
- This detail sheet is to assist in the installation of an **internally located, frameless finish** to a DS1900 Gas Fire.
- Escea recommends when using these finishing methods that a **10-12mm substrate** is used.
- Use care when brick laying to avoid damaging powdercoated black fireplace reveals - protect fire from damage and use a damp sponge to remove excess mortar.
- Black fireplace reveals must be able to be removed - ensure any adhesive or mortar is kept clear.
- Allow for construction tolerance when setting out the opening within the Brick wall.
- First course above fire must have a good bond to the substrate.
- This technical sheet must be read in conjunction with the Escea DS Series Installation Manual, the latest version can be found on our website at www.escea.com.

GENERAL CONSTRUCTION AND FINISHES SHOWN INDICATIVE ONLY

Contact the **ESCEA Architectural Advisory Team** for assistance with the specification of this fire - aa@escea.com