



**Concrete Detail**

scale 1:2

**Notes:**

- All dimensions are in mm. DO NOT SCALE OFF THESE DRAWINGS
- This detail sheet is to assist in the installation of an **internally located, frameless finish** to a DS1900 Gas Fireplace.
- Use care at installation to avoid damaging powdercoated black fireplace reveals - protect fire from damage and use a damp sponge to remove excess adhesive or concrete.
- Black fireplace reveals must be able to be removed - ensure any adhesive or mortar is kept clear.
- Allow for construction tolerance when setting out the opening within the precast/in-situ concrete wall.
- This technical sheet must be read in conjunction with the Escea DS Series Installation Manual, the latest version can be found on our website at [www.escea.com](http://www.escea.com).

GENERAL CONSTRUCTION AND FINISHES SHOWN INDICATIVE ONLY

Contact the ESCEA Architectural Advisory Team for assistance with the specification of this fire - [aa@escea.com](mailto:aa@escea.com)