



Accessory Installation Instruction

EK Series Pizza Oven

Product components




Pizza Oven




Pizza Oven Bricks

Installation

1. Insert the empty Pizza Oven into the EK racking. We recommend a height anywhere between the lowest point to halfway up; dependent on the wood chosen and the intended height of the embers or woodfire.



2. Insert Pizza Oven Bricks



Accessory Installation Instruction

EK Series Pizza Oven

User guide

The two options for heating your Pizza Oven are to start a fire in the Ember Generator and rake the embers across, or start the fire directly underneath the Pizza Oven and let it burn down to embers. Inserting additional small logs of wood every 5-10 minutes is recommended to ensure an even source of heat.

Allow atleast 40+ minutes for the heat to build up within the Pizza Oven Bricks.

Use the provided Pizza Paddle to place the pizza into the oven.

Regularly rotate the pizza to ensure even cooking.

Oven removal instructions after cooking:

Rake any burning wood or embers away from under the Pizza Oven and allow to cool for at least 20 minutes before attempting to remove the Pizza Oven (Gloves provided with the fireplace must be used for this process)

Safety

Do not touch the pizza oven while exposed to active sources of heat.

Supervise children.