


Side Clearance scale 1:5

for further information on running the flue refer to **Sec. C8** of the Escea DS Series Installation Manual which can be downloaded from our website - www.escea.com/nz/technical/

note:

- It is advisable to secure the flexible flue to prevent movement, vibration and sagging - this will also assist in maintaining the required 50mm standoff



Side Clearance scale 1:5

50mm clearance to all combustible surfaces for the first 1200mm of the exhaust flue - zero clearance beyond this point

IMPORTANT:

This technical sheet must be read in conjunction with the Escea DS Series Installation Manual, the latest version can be found on our website www.escea.com/nz/technical/

Contact the **ESCEA Architectural Advisory Team** for assistance with installation of this fire - aa@escea.com

file: DS SERIES MASTER FILE.dwg	scale: 1:5	ecn: ECN-2669	drawing no: EDA-0254	revision: 001	date: 13.10.2017	drawn: MG
------------------------------------	----------------------	-------------------------	--------------------------------	-------------------------	----------------------------	---------------------