



**Flue Detail**

scale 1:10

- note:**
- DO NOT SCALE OFF THESE DRAWINGS. All dimensions are in mm.
  - The **External Vertical Powerflue** should be used in situations where roof access for servicing the Powerflue Fan is more suitable.
  - It is advisable to secure the flexible flue to prevent movement, vibration and sagging - this will also assist in maintaining the required 50mm standoff where required.
  - Construction requirements including venting, moisture control and insulation shown for illustrative purposes only. Confirm specific regulatory requirements.
  - The flue terminal will get very hot when in use. Precautions should be taken to protect people and animals from injury.
  - This technical sheet must be read in conjunction with the relevant Escea Gas Fireplace Installation Manual, the latest version can be found on our website at [www.escea.com](http://www.escea.com).

GENERAL CONSTRUCTION AND FINISHES SHOWN INDICATIVE ONLY

Contact the ESCEA Architectural Advisory Team for assistance with the specification of this fire - [aa@escea.com](mailto:aa@escea.com)