# FIRE BY ESCEO.

### SPECIFICATIONS

Powered direct-vent, co-linear flue
Roof or wall mounted terminations
400mm
4m
12m
40m
1.5m
100 and 75mm Ø (ID) flue pipes
DF700 - 50mm for first 900mm of flue
DF960/990 - 50mm for first 600mm of flue
Max. 10 bends in any flue run
R 1.45
Up to 230° C
Supplied from Fireplace


### TECHNICAL INFORMATION

- Escea Gas Fireplaces must use a Powered Direct Vent flue system, comprising a flue terminal, co-linear flexible flue pipes, and flue extensions as needed
- Flue pathways can be vertical, horizontal, or mixed, extending up to 40m.
- Flue placement must comply with AS/NZS 5601.1 and DF Series clearances.
- The flue fan must remain accessible for servicing.
- PolyPro Flue extensions require a condensate trap draining to the sewer.

### **FLUE SELECTION STEPS**

- Flue Terminal Choose the flue terminal location, on the wall or roof. This
  dictates the standard flue kit used.
- Flue Pathway Establish a pathway from the fireplace to the flue terminal, calculating all vertical and horizontal runs.
- Flue Components Establish the method and components required to complete the flue system using the table below.

## **FLUE SELECTION TABLE**



## STANDARD FLUE KIT OPTIONS AND PATHWAYS

### Horizontal Powerflue (#906641)

For flue terminations through an external wall.

Minimum wall cavity opening requirements:

With wall fixing brackets: 350mm W x 300mm H


Without wall fixing brackets: 296mm W x 296mm H

## External Vertical Powerflue (#906617)

Used in situations where there is no roof space, or where servicing the flue fan is best undertaken from the roof or chimney top (preferred method). Min. flue height above roof surface: **500mm** Liner roof penetration: **225mm**  $\phi$ .

## Internal Vertical Powerflue (#906618)

Suitable for installations where the flue fan must be located in a roof space, or in exposed coastal locations. Min. flue height above roof surface: 500mm Liner roof penetration:  $225mm \not O$ .




Flue Specification Guide



## **EXAMPLE BUILDING**

Multiple flue pathways are possible using the Escea Powered Direct Vent Flue System. The installation and final location of the flue terminal must comply with the relevant Escea Installation Instructions and AS/NZS5601 Gas Installations. These provide guidance for clearances from the flue terminal to other elements of the building. Non-compliance to these clearances may decrease performance of the fire or flue, and/or pose a safety risk to the building users.





For Installation methods not covered in this document please contact: Email: <a href="mailto:aa@escea.com">aa@escea.com</a> PH (NZ): **0800 17 3000** PH (AU): **1800 460 832**